BJ3326 MOVEMENT INSTRUCTION

LIGHT（A Key）———   ———（D Key）START

MODE （B Key）———   ———（C Key）RESET

A . Features

- ➢ 6 Digits LCD Display，Display Hour ,Minute ,Second ,Month ,Day and Week
- ➢ Daily Alarm and Chime hourly
- ➢ Snooze
- ➢ 12 / 24H format selectable
- ➢ 1/100 second Chronograph with split functions
- ➢ EL backlight

B . 0perational Manual

Real Time →B Key→ Chronograph →B Key→ Alarm →B Key→ Time setting

1. **At any state ,press A key EL backlight for 3s .**

2. **Real Time**
- ➢ Press C key to display Alarm ;Press D key to display Date .
- ➢ Turn On / Off Alarm and Chime
  a). Press C＋D key to turn on / off Alarm ,indicator " **ALM** "displaying for On .
  b). Press C＋B key to turn On / Off Chime ,all days of week displaying for On .

3. **Chronograph**
- ➢ The display range of the Chronograph is 23 hours ,59 minutes ,59.99 seconds.
- ➢ Stopwatch time of 0.01 seconds at the beginning; 30 minutes to seconds time.
- ➢ Press D key to Start/Stop running ;
- ➢ When stop ,press C key to zero .
- ➢ When running ,press C key to split count.
- ➢ Then press D key to exit split count ,and stop counting ;
- ➢ When exit split count ,press C key to display all counts ; and press C key again to zero ;
- ➢ When running ,press B key to return to Real Time Mode ,and it running at back .

4. **Daily Alarm**
- ➢ "Hour " flashing once entry Daily Alarm .
- ➢ Press C key to select "Hour " or "Minute "setting
- ➢ Press D key to adjust the flashing item
- ➢ Press C key to confirm
- ➢ Press B key to return to Real Time mode
- ➢ Alarm Snooze ON/OFF

  At Alarm sounding state ,press C key to stop sounding ,and press D key to ON/OFF snooze function .When Snooze function be ON ,it will sound five minutes later ,and auto stop after sounding for a minute .

5. Time Setting

"Second " flashing when loading ,press D key to zero ; Press C key to select item as following sequence :
Minute ⟶ Hour ⟶ Day ⟶ Month ⟶ Week

➢ Press D key to adjust the flashing item.
➢ When setting "Hour " ,"Ｈ" display for ２４H format ;"Ａ" or "Ｐ" for １２H format .
➢ Press D key while the seconds are in the range of 30 to 59 resets them to 00 and adds 1 to the minutes .
   In the range of 00 to 29,the minutes are unchanged.

C. Specifications

➢ Module Size   ：Φ33.25mm   （Exclude outstanding）
➢ Module Thickness   ：9.60mm   （include buzzer）
➢ Operational Temperature Range   ：-10℃~60℃
➢ Operational Voltage   ：3.0V
➢ Accuracy   ：±90sec/month
➢ Battery Code   ：CR2025(capacitance: 170m Ah)
➢ static average current   ：≤1.28uA   (static maximum current ： 3.5uA)
➢ EL lighten average current   ：≤7.89mA   （ELlighten maximum current ： 10mA）
➢ Alarm average current   ：≤1.43 mA   （Alarm maximum current ： 6.0mA）
➢ Battery life   ：≥24 month(Japan Lithium)

（Battery life calculate according to EL lighten four time each day for 3 second each time , alarm foe 60 seconds
 each day）

	Prepared	Checked	Approved
Name	冯碧颜	徐治中	宋检望
Date	10/06/30	10/06/30	10/06/30