


## **BJ3485** MOVEMENT INSTRUCTION



#### A. Features

- > Display Hour ,Minute ,Second ,Month ,Day and Week
- ➤ Daily Alarm and Chime hourly, snooze functions
- ➤ 12 / 24H format selectable
- > 4year calendar
- ➤ Chronograph functions(The display range of the Chronograph is 23 hours ,59 minutes ,59.99 seconds)

### **B**. Operational Manual



### 1. At any state, Press C key On / Off LCD display.

#### 2. Chronograph

- The display range of the Chronograph is 23 hours, 59 minutes, 59.99 seconds.
- Press D key to Start/Stop running;
- When stop, press A key to zero.
- When running, press A key to split count.
- Then press D key to exit split count, and stop counting;
- When exit split count press A key to display all counts; and press A key again to zero;
- When running, press B key to return to Real Time Mode, and it running at back.

#### 3. Daily Alarm

- > Turn On / Off Alarm and Chime Press D key to turn on/off Alarm ( > ) or Chime ( ).
- Alarm setting: Press A key to select "Hour" or "Minute "setting, Press D key to adjust the flashing item, Press A key to confirm, Press B key to return to Real Time mode. When the time goes to the alarm time you set, it will ring bell for 20seconds.
- ➤ Alarm Snooze functions
  At Alarm sounding state, press B key to snooze function. It will sound five minutes later, and auto stop after sounding for 20 Second.
- At alarm sounding state, press A or D, C key stop the alarm ofter sounding.

2012-09-26 Model: BJ3485 Page: 1 / 2 Edition: B



# **BJ3485** MOVEMENT INSTRUCTION



#### 4. Time Setting

- In the time setting mode, "Second " flashing when loading, Press A key" Hour ", Press A key to select item as following in sequence:
  - Hour → Minute → Month → Day → Week
- > Press D key to adjust the flashing item.
- > Press D key while the seconds are in the range of 30 to 59 resets them to 00 and adds 1 to the minutes. In the range of 00 to 29, the minutes are unchanged.

## C. Specifications

➤ Module Size : Ф40.20mm

➤ Module Thickness (include buzzer): 10.0mm

➤ Operational Temperature Range : -10°C~60°C

Operational Voltage : 3.0V

 $\triangleright$  Accuracy :  $\pm 90 \text{sec/month}$ 

➤ Battery Code : CR2016(capacitance:90m Ah)

Static average current
 Static average current
 Static average current
 Static average current
 Static maximum current
 Alarm maximum current
 Static maximum current
 Alarm maximum current
 Static maximum current
 Alarm maximum current

➤ Battery life : ≥18 month (Japan Lithium)

Under the following conditions: (60 seconds of alarm operation per day)

	Prepared	Checked	Approve
Name	冯碧颜	徐治中	宋检望
Date	12/09/26	12/09/26	12/09/26

2012-09-26 Model: BJ3485 Page: 2 / 2 Edition: B