



—— (A Key) SET

—— (B Key) MODE

A . Features

- 3.5 Digits LCD Display, Display Hour ,Minute ,Second ,Month and Day .

B . Operational Manual

1. At time setting mode ,press A key to activate auto advance function.
2. press A key once displaying Date ;twice displaying Second , Press A key again to return to Real Time mode .

3. TIME SETTING

- Press B key twice to entry Time Setting mode ,select item in turn as following :
 Month → Day → Hour → Minute
- Press A key to adjust the flashing item
- Press B key to confirm

C. Specifications

- Module Dimension(including protrusion) : 20.25*16.25mm
- Module Thickness(without buzzer) : 5.2^{+0.2}₋₀ mm
- Operational Temperature Range : -10°C~60°C
- Operational Voltage : 1.5V
- Accuracy : ±90sec/month
- Battery Code : SR626
- Static Maximum Driving Current : ≤2.5 u A(T=25°C)
- Static Average Driving Current : ≤2.0 u A(T=25°C)
- Battery life : 12 months (made in Japan)

	Prepared	Checked	Approve
Name	冯碧颜	徐治中	宋检望
Date	08/07/01	08/07/01	08/07/01