

## **BJ3665** MOVEMENT INSTRUCTION






#### A . Features


- ➤ 4 Digits LCD Display, Display Hour, Minute, Second, Year(2000年~2099年)、Month, Day and Week
- ➤ Daily Alarm and Chime hourly
- ➤ 12 / 24H format selectable, Auto Calendar
- ➤ 1/100 second Chronograph with split functions
- ➤ At any state ,press A key EL for 3s .
- ➤ Key tone

### **B**. Operational Manual



#### 1. Real Time

- > Use the Real Time Mode to set and view the current time and date.
- In the Real Time Mode. Press D key to view the current date, Release D key will return the Real Time Mode
- To set the time and date:
  - a). In the Real Time Mode. Press C key until the minutes start to flash, which indicates the setting screen.
  - b). Press B key to move the flashing in the sequence shown below to select other settings shown.



c). When the setting you want to change is flashing, press D key to change it as described below.

change this setting	Perform this button operation	
Minutes, Hour, Year, Month, Day	Press D key to increase the setting	
12/24Hour	Press D key to change he 12-hour format or 24-hour format	

- d). The day of the week is automatically displayed in accordance with the date (year, month, and day) settings.
- e). With the 12-hour format, the P (PM) indicator appears to the left of the hour digits for times in the range of noon to 11:59 p.m. and no indicator appears to the left of the hour digits for times in the range of midnight to 11:59 a.m.
- f). With the 24-hour format, times are displayed in the range of 0:00 to 23:59, the P (PM) indicator not appears to the left of the hour digits for times, The 24H indicator appears to the under of the hour digits for

2015-03-17 Model: BJ3665 Page: 1/3 Edition : A



## **BJ3665** MOVEMENT INSTRUCTION



times.

g). The 12-hour/24-hour timekeeping format you select in the Real Time Mode is applied in all other modes.

#### 2. Second Display Mode

Use the Second Mode to view the current second of the Real Time Mode.


#### 3. Daily Alarm

- > Set the hour and minutes for the alarm time. The alarm sound will be active everyday by enable alarm function.
- Alarm Operation: The alarm tone sounds at the preset time for about 30 seconds. Pressing any button stops the alarm tone operation.
- > Turn On / Off Alarm and Chime
  - Press D key to turn on/off Alarm (" (((\*))) ") or Chime
  - The indicator (" (((C)))") is shown the Alarm Signal on. All the day of the week is displayed In the Alarm screen is shown the Chime on.
- Alarm setting: In the Alarm Mode, press C key until the minute setting of the alarm time starts to flash, Press B key to select "Hour" or "Minute "setting, Press D key to adjust the flashing item, Press C key to confirm.

#### 4. Chronograph

- The Chronograph lets you count elapsed time, split times, and two finishes.
- The display range of the Chronograph is 29 minutes, 59seconds, and 1/100 second...
- > "SPL" is displayed in the stopwatch mode at split time. When the stopwatch is counting, the "SPL" is flashing. When the stopwatch stop, the "SPL" is always on.
- The stopwatch will be count to max. values and restart from zero until you stop it.
- Press B key to change different mode, it will clears the split time.

To measure times with the stopwatch



2015-03-17 Model: BJ3665 Page: 2 / 3 Edition : A



# **BJ3665** MOVEMENT INSTRUCTION



### C. Specifications

➤ Module Size

➤ Module Thickness (include buzzer)

> Operational Temperature Range

Operational Voltage

> Accuracy

> Battery Code

> static average current

Alarm average currentEL lighten average current

➤ Battery life (85%)

: Ф27.20mm

: 8.6mm

: -10°C~60°C

: 3.0V

:  $\pm 60 \text{sec/month}$ 

: CR2025(capacitance: 170m Ah)

:  $\leq 1.25 \,\mathrm{uA}$  (static maximum current : 3.5uA)

:  $\leq 1.12 \text{m A}$  (Alarm maximum current : 6.0mA)

:  $\leq$ 9.11m A (ELlighten maximum current : 11mA)

: ≥48 month(Japan Lithium)

(Battery life calculate according to EL lighten four time each day for 3 second each time , alarm foe 60 seconds each day)

	Prepared	Checked	Approve
Name	冯碧颜	赵星亮	刘成恒
Date	15/03/16	15/03/16	15/03/16

2015-03-17 Model: BJ3665 Page: 3/3 Edition: A